

Advance Rotating Platform Control



PV360

ORTECH
Professional Lighting™

Table of Contents

- Parts Included 4
- Benefits and Features 5
- PV360 System Setup 5
- Using the PV360 7
- Warranty 7
- Compatible Cameras 8

DISCLAIMER

- While every effort has been made to ensure that the information contained in this guide is accurate and complete, no liability can be accepted for any errors or omissions.
- OR Technologies reserves the right to change the specifications of the hardware and software described herein at any time without prior notice.
- No part of this guide may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language in any form, by any means, without the prior written permission of OR Technologies.
- OR Technologies makes no warranties for damages resulting from corrupted or lost data due to a mistaken operation or malfunction of the camera, the software, the OR Tech lighting systems, personal computers or peripheral devices.



Advance Rotating Platform Control Manual

***Please make sure the system arrives in perfect condition and all parts are included.
Contact us immediately if there is any damage or if you are missing any parts.***

Introduction

Thank you for choosing the OR Tech Advance Rotating Platform Control. This guide will help you understand how to setup your PV360 Remote Control with your camera and rotating platform (sold separately). The steps are very easy to understand and after your finish the setup process, you will be able to start taking pictures to create a wonderful 360 view of your products on the computer (360 product view software not included).

Parts Included

- 1 Advance Rotating Platform Control
- 1 Rotating Platform Connection Cable
- 1 9v Battery



- *Note: Accessories and parts included may differ from those listed in this manual, please check our website (www.or-tech.com) for the most up-to-date information.*

Benefits and Features

- Create a sequence of images to generate a 360 view of any product (360RP rotating platform necessary).
- Turntable stops at each angle to ensure image clarity.
- Easily record 360° product videos and optimize them for eCommerce.

PV360 System Setup

1. Connect the control (**Cable A on picture #1**) to the camera. Every control is sold with a different connector, for example the connector for the Canon camera is not the same as the connector of the Sony camera or Nikon camera (see samples of connectors below). Before you continue with this manual please make sure you have the correct control for your camera.



Sony



Canon



Nikon

2. Connect the control (**Cable B on Picture #1**) to the rotating platform (Model 360RP20 or 360RP25), please make sure the cable is connected all the way in to keep a good communication between the control and the rotating platform.

Picture # 1



3. After you finish the connections, you need to point the camera to the center of the rotating platform (**Picture #2**).



Picture # 2

Using the PV360

Using the PV360 Remote Control is simple, after you connect everything and point the camera to the center of the platform, you can create a video or series of pictures to generate a 360° view of the product.



Turning on the Control.

Turn on the control by pressing the power switch, on the top left side you will see the red led light indicator turn on; control is ready to use. If the Led light does not turn on please check the battery inside.

Creating a Video.

Press the **Green** button on the control to rotate the platform indefinitely to take videos with your camera (you need to adjust the camera manually). To stop just press the **Red** button.

Creating a series of pictures. (60 pictures per complete rotation)

Press the **Red** button on the control to start the sequence of pictures, please make sure the camera is on Manual focus and you have the right settings (check our support section on our website for more information). To stop the sequence press and hold the **Green** button for 3 seconds, if the platform start to rotate indefinitely just press the **Red** button again.

ONE YEAR WARRANTY

Defective components will be replaced during the 12 month warranty period. No charge will be made for labor costs during this period. Proof of purchase must be provided to verify the warranty status.

Compatible Cameras

Sony :

**Sony A77II A99 A57 A37 A35 A65 A77 A450 A560 A580 A33 A55 A850 AS
RM-S1AM/RM-S1LM**

Nikon :

**Nikon Df, D90, D3100, D3200, D3300, D5000, D5100, D5200, D5300,
D5500, D600, D610, D750, D7000, D7100, D7200**

Canon :

**Canon G10, G11, G12, G16, EOS Digital Rebel series, 60D, 70D, Elan II/
IIE, Elan 7/7E, Rebel Ti /2000/G/GII/X/XS, IX/IX Lite, SX50 HS and EOS
Rebel T1i, T2, T2i, T3, T3i, T4i, T5, T5i**



www.or-tech.com | info@or-tech.com

Tel: (619) 661-0628 | Toll Free: (800) 258-6230

**861 Harold Place Suite 209,
Chula Vista, California 91914**